

## Care & Use – Stanley Stainless Steel products

Information on how to treat your Stanley stainless steel products.

### CAUTION!

- Do NOT use in microwave, oven or dishwasher!
- Don't overfill with hot drinks. They could spill and scald you.
- The capacity is designed to be filled just below the lid base.
- For Stainless Steel Mugs: Keep away from kids when filled with hot coffee tea, etc.
- For Stainless Steel Water bottles: Not for use with hot beverages.
- To prevent spills, make sure your lid is screwed on completely before use.
- In order to minimize bacterial growth, do not use to keep warm milk products or baby food.

### CARE & USE OF YOUR STAINLESS STEEL PRODUCT

- Wash before use.
- To clean, washed with warm water and mild detergent. Let stand for five minutes. Pour out and rinse with warm water.
- If interior becomes stained, use a mixture of baking soda and water. Let stand open for one hour before rinsing thoroughly.
- Do not use bleach or cleansers containing chlorine to clean.

**GUARANTEE:** Stanley products are warranted to be free from any defect in workmanship or materials and to be thermally efficient provided used according to the instructions. This warranty does not cover component parts or malfunction due to alteration, misuse, or accident.

If you have any questions regarding this or any other Stanley product, please call our customer service department [nearest you](#). Please note do not return product to retailer.

Stanley is a registered trademark of: Stanley, a brand of PMI

[www.stanley---pmi.com](http://www.stanley---pmi.com)